



Muz Aeroscreen Fastener Kit (All Models)

Installation Instructions

Congratulations on purchasing the Muz Aeroscreen Fastener Kit. Note – This item can be retrofitted to all existing Muz Aeroscreens.

Tools needed:

- None

1) With your roof lowered open the glovebox and remove the nuts from the bolts that hold the aeroscreen in place. Remove the bolts and then insert the new stainless bolts through the current holes from the underside of the glovebox lid. (The opposite way to the original install).

2) Slip the aeroscreen over the protruding bolts so that they fit through the holes in the aeroscreen base.

3) Screw the supplied black plastic lobe knobs onto the bolt ends and hand tighten.

Congratulations. You have successfully installed the Muz Aeroscreen Fastener Kit!

Thank you for your purchase! We hope you enjoy our product!

<i>Muz' Accessories</i>	<i>FREE Screensaver!</i>
See our full range of accessories at www.prestigeautoaccessories.com	Download from www.prestigeautoaccessories.com/downloads