



Muz Aeroscreen (S2000)

Installation Instructions

Congratulations on purchasing the Muz Aeroscreen. Note: High quality black lobe knobs and stainless bolts have replaced the superseded fasteners shown in some images below.

Tools needed:

- Drill
- 5.5mm Drill Bit

1) Drill the 2 holes already pre-placed for you by Honda. You will find the pre-marked spot in the underside of the upper glovebox lid. Drilling from the inside use a smaller drill bit first and then go up in sizes to 5.5mm (0.21").



2) Peel off the bottom protective covering.



3) Peel off the upper side of the bottom protective covering.



4) Place the screen over the 2 holes in the console compartment lid and insert two 5mm X 20mm (0.19"x3/4") stainless bolts through the holes from the underside of the Glovebox lid.



5) Tighten with the included lobe knobs (for easy install or removal later on).



6) Peel the rest of the protective covering off the back of the screen.



7) Peel the rest of the protective covering off the front of the screen.



Congratulations. You have successfully installed the Muz Aeroscreen!



Thank you for your purchase! We hope you enjoy our product!

<i>Muz' Accessories</i> See our full range of accessories at www.prestigeautoaccessories.com	<i>FREE Screensaver!</i> Download from www.prestigeautoaccessories.com/downloads
--	--