



Muz 1 Piece Floormats (S2000)

Installation Instructions

Congratulations on purchasing the Muz 1 Piece Floormats.

Tools needed:

- None

1) This step is optional. Attach the supplied Velcro strips to the underside of the rubber backing of your mats. Run the strips from front to back (not side to side) for maximum grip.

2) Position mats in the vehicle ensuring each mat is sitting neatly in place over the crossbracing of your floorpan. You may need to move the mat around to get it to settle. If you have an anchor post installed ensure that it goes through the eyelet in the driver's mat.

3) Once correctly positioned tuck the edges of the mat down all the way around to ensure it is sitting flat.

4) Tuck down the rear left corner (nearest the seat) of the right hand side mat where it rolls over the transmission hump in the floorpan. The mat will gradually settle into shape under it's own weight over a couple of weeks.

5) Maintain your mats by vacuuming periodically.

Congratulations. You have successfully installed the Muz 1 Piece Floormats!

Thank you for your purchase! We hope you enjoy our product!

Muz' Accessories	FREE Screensaver!
See our full range of accessories at www.prestigeautoaccessories.com	Download from www.prestigeautoaccessories.com/downloads