



Muz Billet Shift Knob (S2000) Installation Instructions

Congratulations on purchasing the Muz Billet Shift Knob.

Tools needed:

- 14mm (9/16) open-ended spanner
- Allen key (provided)

1) Using an adjustable spanner loosen the locknut at the base of the currently installed gear knob.

2) Unscrew the gear knob from the stem in a counter-clockwise direction.

3) For a maximum countersink remove the locknut from the stem.

4) Install your new gear knob by screwing it onto the stem in a clockwise direction until tight. (If you are retaining the locknut in place align the knob and then re-tighten the locknut.

5) Tighten the countersunk hex screw in the base of the knob with the hex key provided (Knobs with gear patterns or logos will need aligning before tightening this key). Tighten the hex screw firmly but do not use excessive force.

6) Maintain with a fine metal polish occasionally such as 'Goddard's Glow' or 'Autosol'.



Congratulations. You have successfully installed the Muz Billet Shift Knob!

Thank you for your purchase! We hope you enjoy our product!

Muz' Accessories See our full range of accessories at www.prestigeautoaccessories.com	FREE Screensaver! Download from www.prestigeautoaccessories.com/downloads
---	---