



Muz JDM Clear Sidemarkers (S2000) Installation Instructions

Congratulations on purchasing the Muz JDM Clear Sidemarkers.

Tools needed:

- *None*

1) Applying firm pressure push the amber side marker toward the front of your car. You will then be able to remove it by lifting the back end of the side marker out from the body. If necessary use a small screwdriver or flat instrument wrapped in cloth to help lift it just enough to get started.



2) Remove the socket assembly by turning it until it releases from the side marker housing. There is no need to unplug the wires from the socket assembly. (We don't want the unplugged wires slipping back inside the body of the fender.)



3) Remove the old bulb from the assembly socket. It is a wedge bulb so you can do this by pulling it straight out. Remove the supplied amber wedge bulb from its packaging and slot it into the socket.



4) Now insert the socket back into you new clear side marker housing. You will need to turn it slightly to lock it properly into place.



5) On the underneath of your side marker housing you will see a plastic spring clip (at the opposite end to the bulb socket) and a small notched tab at the other end (the bulb socket end). To install insert the end with the notched tab toward the back of the vehicle and then apply pressure to snap the end with the spring clip into place.



Congratulations. You have successfully installed the Muz JDM Clear Sidemarkers!

Thank you for your purchase! We hope you enjoy our product!

<i>Muz' Accessories</i> See our full range of accessories at www.prestigeautoaccessories.com	<i>FREE Screensaver!</i> Download from www.prestigeautoaccessories.com/downloads
--	--