



Muz Roof Well Mat (S2000)

Installation Instructions

Congratulations on purchasing the Muz Roof Well Mat.

Tools needed:

- None

- 1) Remove the mat from the box and detach the Velcro tabs.
- 2) Lay the mat on a smooth surface until it returns to it's normal shape. (You may want to place something heavy on the mat to help flatten it ready for installation.)
- 3) If your roof well area **has** been treated with conditioning or protective products you will need to clean your car's roof well with Mineral Turpentine (or equivalent) to remove any residue or oiliness from the surface. (Note – Try not to get this on your paintwork. Apply it to a clean rag first and then wipe the roof well over. Follow up by wiping over with a damp cloth and allow to dry)
- If your roof well **has not** been treated then simply clean the well thoroughly to remove any dust.
- 4) Affix the 4 adhesive Velcro tabs in the appropriate locations in the roof well.
- 5) Position your mat in the roof well with the velour side facing upwards ensuring you have the mat correctly positioned between the indentation on either side of the well for the roof mechanism. Apply downward pressure to affix the mat to the Velcro tabs.
- 6) Check that the roof mechanism is in no way impeded by lowering your roof.

Congratulations. You have successfully installed the Muz Roof Well Mat!

Thank you for your purchase! We hope you enjoy our product!

Muz' Accessories	FREE Screensaver!
See our full range of accessories at www.prestigeautoaccessories.com	Download from www.prestigeautoaccessories.com/downloads